

Turnout Gear

1. Outer Shell

For washing outer Shells.

- **95F/35C° wash**
 - (a) Wash time 15min
 - (b) High (35%) water level
 - (c) Chemical 1 signal for 20sec
 - (d) 50G spin, 30sec
- **Cold high rinse 50G**
 - (a) Wash time 5min
 - (b) High (35%) water level
 - (c) No chemical
 - (d) 50G spin, 30sec
- **Cold high rinse 50G**
 - (a) Wash time 5min
 - (b) High (35%) water level
 - (c) No chemical
 - (d) 50G spin, 30sec
- **Cold high rinse 100G**
 - (a) Wash time 5min
 - (b) High (35%) water level
 - (c) No chemical
 - (d) 100G spin, 5min

Turnout Gear

2. Liners

For washing outer ensemble Liners.

- **95F/35C° wash**
 - (a) Wash time 9min
 - (b) High (35%) water level
 - (c) Chemical 1 signal for 30sec
 - (d) 50G spin, 30sec
- **Cold high rinse 50G**
 - (a) Wash time 5min
 - (b) High (35%) water level
 - (c) No chemical
 - (d) 50G spin, 30sec
- **Cold high rinse 50G**
 - (a) Wash time 5min
 - (b) High (35%) water level
 - (c) No chemical
 - (e) 50G spin, 30sec
- **Cold high rinse 100G**
 - (a) Wash time 5min
 - (b) High (35%) water level
 - (c) No chemical
 - (d) 100G spin, 5min

Turnout Gear

3. Blood Borne

For sanitizing ensemble components exposed to blood or other contaminants.

- **95F/35C° wash**
 - (a) Wash time 10min
 - (b) Low (15%) water level
 - (c) Chemical 2 signal for 30sec
 - (d) 50G spin, 30sec

4. Medium

For medium soiled ensemble components.

- **95F/35C° wash**
 - (a) Wash time 10min
 - (b) High (35%) water level
 - (c) Chemical 1 signal for 20sec
 - (d) 50G spin, 30sec
- **Cold high rinse 50G**
 - (a) Wash time 5min
 - (b) High (35%) water level
 - (c) No chemical
 - (d) 50G spin, 30sec
- **Cold high rinse 50G**
 - (a) Wash time 5min
 - (b) High (35%) water level
 - (c) No chemical
 - (d) 50G spin, 30sec
- **Cold high rinse 100G**
 - (a) Wash time 5min
 - (b) High (35%) water level
 - (c) No chemical
 - (d) 100G spin, 5min

Turnout Gear

5. Cleanout

For cleaning out washer after processing contaminated goods.

- **Fill High 122F/50C°**
 - (a) Wash time 15min
 - (b) High (35%) water level
 - (c) Chemical 1 signal for 20sec
 - (d) Standard Drain
- **Fill High 122F/50C°**
 - (a) Wash time 5min
 - (b) High (35%) water level
 - (c) No chemical
 - (d) Standard Drain
- **Fill High 122F/50C°**
 - (a) Wash time 5min
 - (b) High (35%) water level
 - (c) No chemical
 - (d) Standard Drain
- **Fill High 122F/50C°**
 - (a) Wash time 5min
 - (b) High (35%) water level
 - (c) No chemical
 - (d) Standard Drain

Turnout Gear

6. Cold Wash Prerinse

**Simple cold wash, prerinse with no chemicals.
100G extract**

- **Cold Prerinse**
 - (a) Wash time 1min
 - (b) High (35%) water level
 - (c) No chemical
 - (d) Standard Drain
- **Cold Wash**
 - (a) Wash time 7min
 - (b) Low (15%) water level
 - (c) Chemical 1 and 2 signal for 30sec
 - (d) Standard Drain
- **Cold Bleach Bath**
 - (a) Wash time 4min
 - (b) Low (15%) water level
 - (c) Chemical 3 signal for 30sec
 - (d) Standard Drain
- **Cold Rinse 50G**
 - (a) Wash time 2min
 - (b) High (35%) water level
 - (c) No chemical
 - (d) 50G spin, 30sec
- **Cold Rinse 50G**
 - (a) Wash time 2min
 - (b) High (35%) water level
 - (c) No chemical
 - (d) 50G spin, 30sec
- **Cold Final 100G**
 - (a) Wash time 3min
 - (b) Medium (25%) water level
 - (c) Chemical 4 signal for 30sec
 - (d) 100G spin, 5min

Turnout Gear

7. Warm Wash Pre-rinse

Simple warm wash with warm prerinse.

100G extract

- **Warm Prerinse**
 - (a) Wash time 1min
 - (b) High (35%) water level
 - (c) No chemical
 - (d) Standard Drain
- **Warm Wash**
 - (a) Wash time 7min
 - (b) Low (15%) water level
 - (c) Chemical 1 and 2 signal for 30sec
 - (d) Standard Drain
- **Warm Bleach Bath**
 - (a) Wash time 4min
 - (b) Low (15%) water level
 - (c) Chemical 3 signal for 30sec
 - (d) Standard Drain
- **Warm Rinse 50G**
 - (a) Wash time 2min
 - (b) High (35%) water level
 - (c) No chemical
 - (d) 50G spin, 30sec
- **Warm Rinse 50G**
 - (a) Wash time 2min
 - (b) High (35%) water level
 - (c) No chemical
 - (d) 50G spin, 30sec
- **Warm Final 100G**
 - (a) Wash time 3min
 - (b) Medium (25%) water level
 - (c) Chemical 4 signal for 30sec
 - (d) 100G spin, 5min

Turnout Gear

8. Hot Wash Prerinse

Simple hot wash with a prerinse.

100G extract

- **Hot Prerinse**
 - (a) Wash time 1min
 - (b) High (35%) water level
 - (c) No chemical
 - (d) Standard Drain
- **Hot Wash**
 - (a) Wash time 7min
 - (b) Low (15%) water level
 - (c) Chemical 1 and 2 signal for 30sec
 - (d) Standard Drain
- **Hot Bleach Bath**
 - (a) Wash time 4min
 - (b) Low (15%) water level
 - (c) Chemical 3 signal for 30sec
 - (d) Standard Drain
- **Hot rinse 50G**
 - (a) Wash time 2min
 - (b) High (35%) water level
 - (c) No chemical
 - (d) 50G spin, 30sec
- **Hot rinse 50G**
 - (a) Wash time 2min
 - (b) High (35%) water level
 - (c) No chemical
 - (d) 50G spin, 30sec
- **Hot Final 100G**
 - (a) Wash time 3min
 - (b) Medium (25%) water level
 - (c) Chemical 4 signal for 30sec
 - (d) 100G spin, 5min

Turnout Gear

9. Warm Gentle

**Simple cold gentle wash with prewash.
100G extract**

- **Warm Gent Prewash**
 - (a) Wash time 4min
 - (b) High (35%) water level
 - (c) Chemical 1 signal for 30sec
 - (d) Standard Drain
- **Warm Gent Wash**
 - (a) Wash time 7min
 - (b) Low (15%) water level
 - (c) Chemical 2 signal for 30sec
 - (d) Standard Drain
- **Warm Gent Rinse, 50G**
 - (a) Wash time 2min
 - (b) High (35%) water level
 - (c) No chemical
 - (d) 50G spin, 30sec
- **Warm Gent Rinse, 50G**
 - (a) Wash time 2min
 - (b) High (35%) water level
 - (c) No chemical
 - (d) 50G spin, 30sec
- **Warm Gent final Rinse, 100G**
 - (a) Wash time 3min
 - (b) Medium (25%) water level
 - (c) Chemical 4 signal for 30sec
 - (d) 100G spin, 5min

Turnout Gear

10. Cold Gentle

Simple cold gentle wash with prewash.

100G extract

- **Cold Gent prewash**
 - (a) Wash time 4min
 - (b) High (35%) water level
 - (c) Chemical 1 signal for 30sec
 - (d) No Drain
- **Cold Gentle wash**
 - (a) Wash time 7min
 - (b) Low (15%) water level
 - (c) Chemical 1 and 2 signal for 30sec
 - (d) Standard Drain
- **Cold Gentle rinse, 50G**
 - (a) Wash time 2min
 - (b) High (35%) water level
 - (c) No chemical
 - (d) 50G spin, 30sec
- **Cold Gentle rinse, 50G**
 - (a) Wash time 2min
 - (b) High (35%) water level
 - (c) No chemical
 - (d) 50G spin, 30sec
- **Cold Gent final 100G**
 - (a) Wash time 3min
 - (b) Medium (25%) water level
 - (c) Chemical 4 signal for 30sec
 - (d) 100G spin, 5min

Turnout Gear

11. Rinse and Spin

Cold rinse and spin 100Gs.

- **Cold Final 100G**
 - (a) Wash time 3min
 - (b) Medium (25%) water level
 - (c) Chemical 4 signal for 30sec
 - (d) 100G spin, 5min